

## BC-216/204 LOAD DEFAULT SETTING

1. power off
2. press MODE and ENETR button, and power on , when the LCD shows LOAD DEFAULT
3. loose hand