





Power on shows “update firmware”

issue	Power on shows “update firmware”
Checking procedure:	<p>1、 before power on, press MODE 、 + 、 ENTER three buttons, and power on, controller shows used default IP address:192.168.0.50</p>  <p>Release buttons, controller shows update firmware.</p>  <p>2、 ping 192.168.0.50, shown as below:</p>  <p>If data return, means the net port is good.</p> <p>3、 open web browser, enter IP 192.168.0.50, shows:</p>



Click "Back", restart, controller will work normally. The website will jump to login page, as shown:

